









Aimiky number	OEM NUMBER	CHINESE NAME	ITEM NAME	CAR MODEL	PHOTO
Aimiky-NIS-003	39101-JD02B;39101JD02B	驱动轴	Drive shaft	Nissan Qashqai	
Aimiky-NIS-004	39100-JD02B;39100JD02B	驱动轴	Drive shaft	Nissan Qashqai	
Aimiky-BT50-001	6L5Z 3A428-AA;6L5Z3A428AA	传动轴CV型连接轴	Drive Shaft CV Joint Axle shaft	BT50	
Aimiky-BT50-002	6L5Z 3A427-AA;6L5Z3A427AA	传动轴CV型连接轴	Drive Shaft CV Joint Axle shaft	BT50	
Aimiky-BT50-004	F87Z3B437AA;MD0925600A	半轴总成	Drive shaft	BT50	
Aimiky-BT50-005	3M353B436AA;1328094;MD2022510A;MD20-25-50XA;MD202550XA;MD20-25-50XB;MD202550XB;MD23-25-50X;MD232550X	驱动轴	Drive shaft	BT50	
Aimiky-BT50-006	2M353B437AA;1339667;2M353B437CB;MD20-25-60XB;MD20-25-60XA;MD202560XB;MD202560XA	传动轴CV型连接轴	Drive shaft CV Joint Axle shaft	BT50	
Aimiky-BT50-091	2039603;5345953;EB3G-3A42-8EA;EB3G3A428EA	驱动轴	Drive shaft	BT50	
Aimiky-BT50-118 LH	Aimiky-BT50-118 LH	驱动轴 左	Drive shaft	BT50 2005-	
Aimiky-BT50-118 RH	Aimiky-BT50-118 RH	驱动轴 右	Drive shaft	BT50 2005-	

Aimiky-BT50-128	1447140;6M34 3B437 CA;6M343B437CA;PP042560X;1447139;	半轴总成	Drive shaft LH	BT50	
Aimiky-BT50-129	PA3327721	驱动轴 28T & 28T	connection shaft	BT50	
Aimiky-BT50-131	MA10-27-700;MA1027700;3665729	驱动轴 26T & 26T	connection shaft 26T & 26T	BT50	
Aimiky-BT50-136	MD0925500A	传动轴CV型连接轴	Drive shaft CV Joint Axle shaft	BT50	
Aimiky-BT50-164	MD23-25-60X;MD232560X	驱动轴	DRIVE SHAFT	MAZDA BT50	
Aimiky-BT50-165	ID00-25-50XA;ID002550XA	驱动轴	Drive shaft	MAZDA BT50 2012/16 RH	
Aimiky-BT50-166	ID00-25-60XA;ID002560XA	驱动轴	Drive shaft	MAZDA BT50 2012/16 LH	
Aimiky-CVL-306	96549139	驱动轴	Drive Shaft	CHEVROLET	
Aimiky-CVL-307	96549094	驱动轴	Drive Shaft	CHEVROLET	
Aimiky-DMax-001	8971390950;8-97139-095-0	驱动轴	Drive Shaft	D-MAX	
Aimiky-DMax-002	8971390960;8-97139-096-0	驱动轴	Drive Shaft	D-MAX	

Aimiky-DMax-065	8-97360-046-0;8973600460;8-97387-674-1;8973876741;8-97387-675-1;8973876751	驱动轴	Drive Shaft 2002-2011	D-MAX 2002-2011	
Aimiky-DMax-080	Aimiky-DMax-080	驱动轴	drive shaft L=R	D-MAX	
Aimiky-DMax-171	Aimiky-DMax-171	驱动轴	drive shaft	D-MAX 2002	
Aimiky-DMax-172	8-97215-697-1;8972156971	驱动轴	drive shaft	D-MAX	
Aimiky-DMAX-191	8981472452;8-98147245-2;8-98147-245-2;98147245	半轴总成	Drive shaft	Dmax	
Aimiky-DMAX-247	8-973867-674-1;89738676741	半轴总成	drive shaft	Isuzu D-max	
Aimiky-FRD-048	PP042550XA;1447177;1447178;6M343B436CA;6M343B436CA	驱动轴 RH	Drive shaft	Ford RANGER	
Aimiky-FRD-056	EB3G 3A427 DA;EB3G3A427DA	驱动轴 右	DRIVE SHAFT	Ford	
Aimiky-FRD-056 L	EB3G 3A428 DA;EB3G3A428DA	驱动轴	DRIVE SHAFT	Ford	
Aimiky-FRD-078	EB3G-4A376-CA;EB3G4A376CA	驱动轴	drive shaft	Ford Ranger 3.2	
Aimiky-FRD-092	EB3G-3A42-7EA;EB3G3A427EA	驱动轴	Driver shaft	Ford Ranger 2.2 3.2	












Aimiky-FRD-093	F87Z3B437AB;MD1825500	半轴总成	Drive shaft	Ford	
Aimiky-FRD-103	UF9T-25-50X;UC9T-25-50XA;EB3G-3A427-DA;EB3G3A427DA; EB3G-3A427-EA; EB3G3A427EA	半轴总成	Drive shaft	FORD L	
Aimiky-FRD-104	EB3G-3A428-DA;EB3G3A428DA;EB3G-3A428-CA;EB3G3A428CA	半轴总成 右	Drive shaft R	FORD	
Aimiky-FRD-105	EB3G-4A376-CA;EB3G4A376CA	半轴总成	Drive shaft	FORD	
Aimiky-FRD-141	UF9T-25-50XB RH;UF9T2550XB;6L5Z 3A428-AA;6L5Z 3A428AA	驱动轴	Driver shaft	FORD RANGER 4WD 11-	
Aimiky-FRD-142	UF9T-25-60XB LH;UF9T2560XB;6L5Z 3A427-AA;6L5Z 3A427AA	驱动轴	Driver shaft	FORD RANGER 4WD 11-	
Aimiky-FRD-286	F87Z3B437AB	驱动轴			
Aimiky-FRD-292	EB3G3A427BB;EB-3G3A427-BB	驱动轴	drive shaft	Ford Ranger	
Aimiky-HDI-510	49500-0X010;495000X010	驱动轴	Drive Shaft	HYUNDAI I10 RH	
Aimiky-HDI-511	49500-0X000;495000X000	驱动轴	Drive Shaft	HYUNDAI I10 RH	
Aimiky-HDI-552	4950038342; 4950038312;495003C342;495003C312	驱动轴	Drive shaft	HYUNDAI	


Aimiky-HDI-553	4950038392	驱动轴	Drive shaft	HYUNDAI	
Aimiky-HDI-592	49120-4A000;491204A000	传动轴滑叉	drive shaft triangle tube	Hyundai	
Aimiky-HDI-613	49120-4F100;491204F100	主动轴接头	DRIVE SHAFT JOINT	HYUNDAI	
Aimiky-HDI-668	49591-4E001	驱动轴	DRIVE SHAFT	HYUNDAI	
Aimiky-HLX-001	43430-35022;4343035022	驱动轴	Drive Shaft	Hilux	
Aimiky-HLX-002	43430-0K020;434300K020;43430-0K022;434300K022	驱动轴	Drive Shaft	Hilux	
Aimiky-HLX-003	43430-0K070;434300K070;43430-0K080	驱动轴	Drive Shaft	Hilux Revo	
Aimiky-HLX-074	37230-35130;3723035130	传动轴中心轴承	Drive Shaft Center Support Bearing	Hilux	
Aimiky-HLX-076	37230-35090;3723035090	传动轴中心轴承	Drive Shaft Center Support Bearing	Hilux	
Aimiky-HLX-077	37230-35120;3723035120	传动轴中心轴承	Drive Shaft Center Support Bearing	Hilux	
Aimiky-HLX-1006	37140-0K102;371400K102	传动轴	Drive shaft	HILUX	 <small>Carban Distributors Hilux 2.8 Manual 2014/2020 371400K102</small>

Aimiky-HLX-1051	43430-0K060;434300K060	驱动轴	Drive Shaft Axle	Toyota Hilux Revo	
Aimiky-HLX-1055	37100-0K273;371000K273	传动轴	drive shaft	Toyota Hilux	
Aimiky-HLX-264	43430-0K020;434300K020	驱动轴	Drive Shaft	Hilux	
Aimiky-HLX-488	37230-0K010;372300K010	传动轴悬挂	Drive shaft suspension	hilux	
Aimiky-HLX-576	43430-60082;4343060082	驱动轴	Drive Shaft	Toyota	
Aimiky-ISZ-015	8981472450;8-98147-245-0	驱动轴	Drive Shaft D-MAX 2012-	D-MAX 2012-	
Aimiky-ISZ-065	8-944230-381CB;8944230381CB	传动轴CV型连接轴	Drive Shaft CV Joint Axle shaft	Isuzu	
Aimiky-ISZ-066	8-944230-371CC;8944230371CC	传动轴CV型连接轴	Drive Shaft CV Joint Axle shaft	Isuzu	
Aimiky-ISZ-294	IZ-8-904;IZ8904	传动轴总成	drive shaft assembly	Isuzu	
Aimiky-ISZ-295	IZ-8-903;IZ8903	传动轴总成	drive shaft assembly	Isuzu	
Aimiky-ISZ-321	8-98147-245-2;8981472452	驱动轴	DRIVE SHAFT	-ISUZUZU TFS87	












Aimiky-ISZ-384	C8983929650;C8983-929650;8983929650;8-98392965-0	驱动轴	DRIVE SHAFT	Isuzu	
Aimiky-ISZ-439	8-94453-696-1 L;8944536961;17T-23T	驱动轴	Axle Shaft	ISUZU TFS	
Aimiky-ISZ-440	8-94423037-0 R;8944230370;17T-23T	驱动轴	Axle Shaft	ISUZU TFS	
Aimiky-ISZ-603	8-944230-381CB;8944230381CB;8-94423-038-1;8944230381	驱动轴	Drive Shaft	ISUZU TFS 4X4	
Aimiky-JC-134	43430-60020;4343060020	传动轴	Drive shaft	Lexus	
Aimiky-JC-136	44305-SHJ-A01-J RH;44305SHJA01J RH	驱动轴	Drive shaft	Honda ODYSSEY 2006/10 RH	
Aimiky-JC-137	44306-SHJ-A01-J LH;44306SHJA01J LH	驱动轴	Drive shaft	Honda ODYSSEY 2006/10 LH	
Aimiky-KIA-115	0K63B25500A;0K63B25600A;49500-4E001;495004E001;0K63B25500C;0K63B-25500C;0K63B25500C	驱动轴	Drive Shaft	KIA	
Aimiky-KIA-119	0K63B25600C;0K63B2-5600C	驱动轴	Drive Shaft	KIA	
Aimiky-KIA-162	49501-4E001; 495014E001	驱动轴	Drive Shaft	KIA BONGO 3 RH	
Aimiky-KIA-471	49501-4E001;495014E001	驱动轴	DRIVE SHAFT	KIA	

Aimiky-L200-001	3815A309;3815A307	驱动轴	Drive Shaft	L200	
Aimiky-L200-002	3815A308;3815A310	驱动轴	Drive Shaft	L200	
Aimiky-L200-003	MR276870	驱动轴	Drive Shaft	L200	
Aimiky-L200-004	MR276871	驱动轴	Drive Shaft	L200	
Aimiky-L200-005	MN107602	驱动轴	Drive Shaft	L200	
Aimiky-L200-006	MN107601	驱动轴	Drive Shaft	L200	
Aimiky-L200-073	MR580647;MR580648	传动轴中心支撑轴承	Drive Shaft Center Support Bearing	L200	
Aimiky-L200-074	MR223119;3450A017;MB154706;MN171429;MR534950	传动轴中心支撑轴承	Drive Shaft Center Support Bearing	L200	
Aimiky-L200-257	MR276869	驱动轴	Drive Shaft	L200	
Aimiky-L200-325	3815A579 LH	驱动轴	Drive shaft	Mitsubishi SPORTERO L-200 2.5 (LH) 2016	
Aimiky-L200-326	3815A580 RH	驱动轴	Drive shaft	Mitsubishi SPORTERO L-200 2.5 (RH) 2016	


Aimiky-MIS-131	MR528647;MR-528647	驱动轴	drive shaft	mitsubishi	
Aimiky-MIS-279	MR-453383;MR453383	驱动轴	Drive shaft	Mitsubishi MONTERO NEW MONTERO (LH) 2001	
Aimiky-MIS-280	MR-453384;MR453384	驱动轴	Drive shaft	Mitsubishi MONTERO NEW MONTERO (RH) 2001	
Aimiky-MIS-281	MR-580377;MR580377	驱动轴	Drive shaft	Mitsubishi LANCER 1.3 01-10 LH	
Aimiky-MIS-282	MR-580377;MR580377	驱动轴	Drive shaft	Mitsubishi LANCER 1.3 01-10 LH	
Aimiky-MIS-283	3815A137 LH	驱动轴	Drive shaft	Mitsubishi OUT LANDER 6B31	
Aimiky-MIS-284	3815A140 RH	驱动轴	Drive shaft	Mitsubishi OUT LANDER 6B31	
Aimiky-MIS-285	3715A031 LH	驱动轴	Drive shaft	LH Mitsubishi OUT LANDER 6B31	
Aimiky-MIS-286	3715A032 RH	驱动轴	Drive shaft	RH Mitsubishi OUT LANDER 6B31	
Aimiky-MIS-438	MB620833	Drive Shaft	Drive Shaft	Mitsubishi	
Aimiky-MIS-439	MB620834	Drive Shaft	Drive Shaft	Mitsubishi	

Aimiky-MZD-001 LH	MZ-8-047;MZ8047	驱动轴 左	Drive shaft	B2500 -2005	
Aimiky-MZD-001 RH	MZ-8-048;MZ8048	驱动轴 右	Drive shaft	B2500 -2005	
Aimiky-MZD-002	UH71-43-900;UH7143900	驱动轴 右	Brake Valve	Mazda	
Aimiky-MZD-035	MD18-25-600;MD1825600	驱动轴	Drive shaft LH No ABS	Ford Ranger 97-01 LH	
Aimiky-MZD-036	MD18-25-500;MD1825500	驱动轴	Drive shaft RH No ABS	Ford Ranger 97-01 RH	
Aimiky-MZD-042	drive shaft inner joint +connecting shaft	轴内接头+连接轴	drive shaft inner joint +connecting shaft	Mazda B2500	
Aimiky-MZD-044	UF9T-95-50X;UF9T9550X	传动轴CV型连接轴	Drive shaft CV Joint Axle shaft	Mazda	
Aimiky-MZD-045	UF9T-95-60X;UF9T9560X	传动轴CV型连接轴	Drive shaft CV Joint Axle shaft	Mazda	
Aimiky-MZD-076	UF9T-25-60X;UF9T2560X	驱动轴	Drive Shaft Axle	Mazda CX7	
Aimiky-MZD-081	MD19 25 50XB;MD192550XB	驱动轴	drive shaft	Mazda	
Aimiky-MZD-082	MD19 26 60XB;MD192660XB	驱动轴	drive shaft	Mazda	

Aimiky-MZD-173	GP18-25-50XA RH;GP182550XA RH	驱动轴	Driveshaft	RH MAZDA 6 ATM	
Aimiky-MZD-219	CV Joint kit	驱动轴接头	Drive shaft joint	Mazda	
Aimiky-MZD-220	MD09-025-500A;MD09025500A	驱动轴 右	DRIVE SHAFT	Mazda B2500 Bravo Ford Ranger Courier 1997-2001	
Aimiky-MZD-221	MD09-025-600A;MD09025600A	驱动轴 左	DRIVE SHAFT	Mazda B2500 Bravo Ford Ranger Courier 1997-2001	
Aimiky-NIS-022	43430-0K040;434300K040;43430-0K022;434300K022	驱动轴	Drive Shaft	TOYOTA HILUX VIGO	
Aimiky-NIS-518	391018H710	驱动轴	DRIVE SHAFT	NISSAN X-Trail	
Aimiky-NIS-838	39100-EB310;39100EB310	驱动轴	Drive shaft	(LR) NISSAN PATHFINDER R51	
Aimiky-NIS-839	39100-JG02C RH;39100JG02C RH	驱动轴	Drive shaft	(RH) NISSAN X-TRAIL T31 (LARGO) ATM	
Aimiky-NIS-840	39101-JG02C LH;39101JG02C LH	驱动轴	Drive shaft	(LH) NISSAN X-TRAIL T31 (CORTO) ATM	
Aimiky-NIS-841	39100-3HCOB RH;391003HCOB RH	驱动轴	Drive shaft	(RH) NISSAN VERSA 2012	
Aimiky-NIS-842	39101-3HCOB LH;391013HCOB LH	驱动轴	Drive shaft	(LH) NISSAN VERSA 2012	

Aimiky-NIS-843	39100-4EF0C RH;391004EF0C RH	驱动轴	Drive shaft	(RH) NISSAN QASHQAI 2015	
Aimiky-NIS-844	39101-4EF0A LH;391014EF0A LH	驱动轴	Drive shaft	(LH) NISSAN QASHQAI 2015	
Aimiky-NIS-845	39100-BB22C RH;39100BB22C RH	驱动轴	Drive shaft	(RH) NISSAN QASHQAI 2008/13	
Aimiky-NIS-846	39101-JD22C LH;39101JD22C LH	驱动轴	Drive shaft	(LH) NISSAN QASHQAI 2008/13	
Aimiky-NIS-847	39100-3KA0A RH;391003KA0A RH	驱动轴	Drive shaft	RH Nissan PATHFINDER R52	
Aimiky-NIS-848	39101-3JA0A LH;391013JA0A LH	驱动轴	Drive shaft	Nissan PATHFINDER R52	
Aimiky-NIS-849	39600-3JA0A RH/LH;396003JA0A RH/LH	驱动轴	Drive shaft	Nissan PATHFINDER R52	
Aimiky-NIS-850	39600-EB310;39600EB310	驱动轴	Drive shaft	RH/LH NISSAN PATHFINDER R51	
Aimiky-NIS-851	39100-ET000 RH;39100ET000 RH	驱动轴	Drive shaft	RH NISSAN SENTRA B16 2,0	
Aimiky-NIS-852	39101-ET000 LH;39101ET000 LH	驱动轴	Drive shaft	LH NISSAN SENTRA B16 2,0	
Aimiky-NIS-853	39100-JD24C RH;39100JD24C RH	驱动轴	Drive shaft	RH NISSAN QASHQAI J10	

Aimiky-NIS-854	39101-JD24C LH;39101JD24C LH	驱动轴	Drive shaft	LH NISSAN QASHQAI J10	
Aimiky-NIS-855	39100-5RD1A RH;391005RD1A RH	驱动轴	Drive shaft	2021 Nissan Versa	
Aimiky-NIS-856	39101-5RD1A LH;391015RD1A LH	驱动轴	Drive shaft	2021 Nissan Versa	
Aimiky-NIS-857	39100-3RC0A RH;391003RC0A RH	驱动轴	Drive shaft	RH Nissan SENTRA B17 2013-2018	
Aimiky-NIS-858	39101-3RC0A LH;391013RC0A LH	驱动轴	Drive shaft	LH Nissan SENTRA B17 2013-2018	
Aimiky-NIS-859	39100-8H615 RH;391008H615 RH	驱动轴	Drive shaft	RH Nissan X-TRAIL T30 2001-2007	
Aimiky-NIS-860	39101-8H315 LH;391018H315 LH	驱动轴	Drive shaft	RH Nissan X-TRAIL T30 2001-2007	
Aimiky-NIS-861	39100-4BA1B RH;391004BA1B RH	驱动轴	Drive shaft	RH Nissan X-TRAIL T32	
Aimiky-NIS-862	39100-CB200 RH;39100CB200 RH	驱动轴	Drive shaft	RH Nissan MURANO Z50	
Aimiky-NIS-863	39101-4BA0B LH;391014BA0B LH	驱动轴	Drive shaft	LH Nissan X-TRAIL T32	
Aimiky-NIS-864	39100-5AA1A RH;391005AA1A RH	驱动轴	Drive shaft	RH NISSAN MURANO Z52 2015-2019	

Aimiky-NIS-865	39101-5AA0D LH;391015AA0D LH	驱动轴	Drive shaft	LH NISSAN MURANO Z52 2015-2019	
Aimiky-NIS-866	39100-AY100 RH;39100AY100 RH	驱动轴	Drive shaft	RH NISSAN MICRA	
Aimiky-NIS-867	39101-AY100 LH;39101AY100 LH	驱动轴	Drive shaft	LH NISSAN MICRA	
Aimiky-NVR-001	39100-EB70A;39100EB70A?	驱动轴	Drive Shaft	Navara	
Aimiky-NVR-002	39100-2S660;391002S660	驱动轴	Drive Shaft	Navara	
Aimiky-NVR-060	37521-57G26;3752157G26;37521-56G25;3752156G25	传动轴支撑轴承	Drive Shaft Center Support Bearing	Navara	
Aimiky-NVR-271	39100-4JA1A;391004JA1A	驱动轴	DRIVE SHAFT	NISSAN NP300	7389
Aimiky-NVR-289	39100-4KH0A;391004KH0A	驱动轴	Drive shaft	NISSAN NAVARA 2005- 2.5AT D40 4WD LHD	
Aimiky-NVR-290	A4703300400;;A4703300300;391004JA2A ; 391004JA0B;391004JA0A	驱动轴	Drive shaft	NISSAN NAVARA 2019	
Aimiky-NVR-302	39100-4JA2A;391004JA2A	驱动轴	Drivershaft	Nissan Navara	
Aimiky-NVR-314	39100-4JA0A; 39100 4JA0A; 391004JA0A	驱动轴 前	Drive shaft	Nissan Navara 2.3 DCI 2017 NP300 Front	

Aimiky-NVR-321	39100-EB70B;39100EB70B	驱动轴	Drive shaft	(LR) NISSAN NAVARRA D40T	
Aimiky-NVR-331	39100-EB300; 39100EB300	驱动轴	DRIVE SHAFT	NISSAN NP300 Navara D40 Pathfinder	
Aimiky-OT-1068	样品 长;Aimiky-OT-1068;43412-60100;4341260100;768MM 长	驱动轴	connection shaft		
Aimiky-OT-1068-1	样品 短;Aimiky-OT-1068-1;43411-60070;4341160070;415mm 长	驱动轴	connection shaft		
Aimiky-OT-1115	A1644100501	传动轴	DRIVE SHAFT	MERCEDES	
Aimiky-OT-1239	2200400P3060	驱动轴	Drive Shaft	JAC T6,T8	
Aimiky-OT-1240	2200300P3060	驱动轴	Drive Shaft	JAC T6,T8	
Aimiky-OT-1274	2203010-P02;2203010P02	传动轴	drive shaft	Great Wall Fengjun	
Aimiky-OT-1410	2H0521101A;2H0521101B;2H0521101C;2H0521101E	传动轴	drive shaft	Volkswagen Amarok	
Aimiky-OT-142	2H0407271D	驱动轴	drive shaft	volkswagen amarok	
Aimiky-OT-1422	1Z-8-06	驱动轴			





Aimiky-OT-1620	长4米, 内径108mm, 外径120mm; Length: 4 meters, Inner diameter: 108 mm ,outer diameter: 120 mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-1621	Length: 2 meters, Inner diameter: 108 mm , outer diameter: 120 mm;长2米, 内径108mm, 外径120mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-1622	Length: 4 meters. Inner diameter: 129.5 mm, outer diameter: 140 mm;长4米, 内径129.5mm, 外径140mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-1623	Length: 2 meters, Inner diameter: 129.5 mm, outer diameter: 140 mm;长2米, 内径129.5mm, 外径140mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-1624	Length: 4 meters, Inner diameter: 118mm, Outer diameter:130mm;长4米, 内径118mm, 外径130mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-1625	Length: 2 meters, Inner diameter :118mm, Outer diameter:130mm;长2米, 内径118mm, 外径130mm	传动轴钢管	Drive shaft steel pipe		
Aimiky-OT-868	样品;3741-2304060-01;3741230406001	半轴	DRIVE SHAFT	LADA	
Aimiky-OT-875	样品;TKU-2304061-65;TKU230406165	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OT-876	样品;TKU-2304061-41;TKU230406141	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OT-877	样品;TKU-2304061-31;TKU230406131	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OT-878	样品;TKU-2304060-65;TKU230406065	半轴总成	DRIVE SHAFT	LADA	

Aimiky-OT-879	样品;TKU-2304060-51;TKU230406051	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OT-880	样品;TKU-2304060-45;TKU230406045	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OT-881	样品;TKU-2304060-41;TKU230406041	半轴总成	DRIVE SHAFT	LADA	
Aimiky-OTH-W019	0504AA0030N	驱动轴	Drive Shaft		
Aimiky-OTH-W020	0504AA0020N	驱动轴	Drive Shaft		
Aimiky-SZK-067	48580-54P51;4858054P51	方向机	REAR DRIVE SHAFT RH	Suzuki Vitara	
Aimiky-SZK-068	44105-61M00;4410561M00	驱动轴	REAR DRIVE SHAFT LH	SUZUKI VITARA	
Aimiky-SZK-069	44106-61M00;4410661M00	驱动轴	FRONT DRIVE SHAFT RH	SUZUKI VITARA	
Aimiky-SZK-070	44101-54PF1;4410154PF1	驱动轴	FRONT DRIVE SHAFT LH	SUZUKI VITARA 2019	
Aimiky-SZK-071	44102-54P61;4410254P61	驱动轴	FRONT DIFFERENTIAL BASE	SUZUKI VITARA 2019	
Aimiky-SZK-084	29000-54P30;2900054P30	前差速器	FRONT DRIVE SHAFT RH SX4	Suzuki Sx4 S-cross	

Aimiky-SZK-085	44101-80J21;4410180J21	驱动轴	FRONT DRIVE SHAFT LH SX4	Suzuki Sx4 S-cross	
Aimiky-SZK-086	44102-80J00;4410280J00	驱动轴	FRONT DRIVE SHAFT RH S-CROSS BENZ.	Suzuki Sx4 S-cross	
Aimiky-SZK-087	44101-61M11;4410161M11	驱动轴	FRONT DRIVE SHAFT LH S-CROSS BENZ	Suzuki Sx4	
Aimiky-SZK-088	44102-61M11;4410261M11	驱动轴	FRONT DRIVE SHAFT RH S-CROSS D?ESEL	Suzuki Sx4	
Aimiky-SZK-089	44101-61MC1;4410161MC1	驱动轴	OINT ASSY, DIFF SIDE RH	SUZUKI VITARA	
Aimiky-SZK-113	44101-67D01;4410167D01	驱动轴	Drive Shaft	Suzuki	
Aimiky-SZK-114	44102-67D00;4410267D00	驱动轴	Drive Shaft	Suzuki	
Aimiky-SZK-117	44101-65J00;4410165J00;44102-65J00;4410265J00	驱动轴	Drive Shaft	Suzuki Vitara	
Aimiky-SZK-291	44101-54P12;4410154P12	驱动轴	drive shaft	SUZUKI VITARA 1.6	
Aimiky-SZK-292	44102-54P11;4410254P11	驱动轴	drive shaft	SUZUKI VITARA 1.6	
Aimiky-SZK-301	44101-61M01;4410161M01	驱动轴	Axles FR	SUZUKI VITARA	

Aimiky-SZK-302	44102-61M01;4410261M01	驱动轴前左	Axles FL	SUZUKI VITARA	
Aimiky-SZK-555	27102-66J11;2710266J11	传动轴	drive shaft	Suzuki Grand Vitara	
Aimiky-SZK-620	ALTO80002;857157	驱动轴防尘套修包 18T	Drive Shaft Boot Kit	SUZUKI	
Aimiky-TYT-1017	43430-60040;4343060040	驱动轴	drive shaft	Toyota	
Aimiky-TYT-1047	4343004070;43430-04070;43430-60082;4343060082;Aimiky -HLX-576通用	驱动轴	Drive Shaft	Toyota	
Aimiky-TYT-1368	43430-60071;4343060071	驱动轴	Drive Shaft	Toyota Land Cruiser 100	
Aimiky-TYT-1405	0442760120;04427-60120	驱动轴防尘套修包	Drive Shaft Boot Kit	Toyota	
Aimiky-TYT-1406	0442760090;04427-60090;0442760092;04427-60092	驱动轴防尘套修包	Drive Shaft Boot Kit	Toyota	
Aimiky-TYT-1544	43410-12A80 RH;4341012A80 RH	驱动轴	Drive shaft	RH TOYOTA COROLLA 2008	
Aimiky-TYT-1545	43420-12A10 LH;4342012A10 LH	驱动轴	Drive shaft	LH TOYOTA COROLLA 2008	
Aimiky-TYT-1546	43430-60070;4343060070	驱动轴	Drive shaft	L/RToyota SAHARA 200 Land Cruiser VDJ200	

Aimiky-TYT-1547	43410-42170 RH;4341042170 RH	驱动轴	Drive shaft	TOYOTA RAV 4 2005	
Aimiky-TYT-1548	43420-42170 LH;4342042170 LH	驱动轴	Drive shaft	TOYOTA RAV 4 2005	
Aimiky-TYT-1549	43410-02710 RH;4341002710 RH	驱动轴	Drive shaft	RH TOYOTA COROLLA 2ZR 2013	
Aimiky-TYT-1550	4342002710 LH;43420-02710 LH	驱动轴	Drive shaft	LH TOYOTA COROLLA 2ZR 2013	
Aimiky-TYT-1551	43410-52070 RH;4341052070 RH	驱动轴	Drive shaft	RH TOYOTA YARIS CON ABS	
Aimiky-TYT-1552	43420-52070 LH;4342052070 LH	驱动轴	Drive shaft	LH TOYOTA YARIS CON ABS	
Aimiky-TYT-1554	43410-42021 RH;4341042021 RH	驱动轴	Drive shaft	RH TOYOTA RAV 4 1998	
Aimiky-TYT-1555	43420-42021 LH;4342042021 LH	驱动轴	Drive shaft	LH TOYOTA RAV 4 1998	
Aimiky-TYT-1590	43430-35011;4343035011	驱动轴	DRIVE SHAFT	Toyota	
Aimiky-TYT-1877	4341052210;43410-52210	传动轴	Drive Shaft	Toyota	
Aimiky-TYT-2143	37140-0K040;371400K040	传动轴	drive shaft	Toyota	

Aimiky-TYT-2445	37140-0k060;371400k060	传动轴	drive shaft	TOYOTA	
Aimiky-TYT-2668	43430-60080; 4343060080	驱动轴	Drive Shaft	Toyota Land Cruiser 2002	
Aimiky-TYT-456	04374-28010;0437428010	传动轴套件	DRIVE SHAFT COUPLING	TOYOTA	
Aimiky-TYT-749	37110-6A650;371106A650	驱动轴	Shaft	TOYOTA	
Aimiky-TYT-763	43430-60060;4343060060;43430-60061;4343060061	驱动轴	Drive Shaft	Toyota	